

# CLAW PLAST

## Handling Instructions

## Panel Adhesive•Filler

### Directions for Use

**Preparation:** Grind surface with No. 16 grit paper or No. 40 coarse sandpaper to remove all rust and moisture.

**Mixing:** Using a clean tool, transfer the desired amount of filler to a clean non-absorbent surface. Knead the “hardener” and add in proportion to the amount supplied. Using a separate clean tool, mix the filler and hardener together until a uniform color mix results. When mixing, use a circular rubbing motion to avoid air entrapment. Do not whip or stir air into mixture.

**Application:** When humidity is high, or room temperature is below normal 70°F., warm up the area to be repaired- to eliminate all traces of moisture. Then, with a firm pressure, spread an initial thin layer of filler. Reapply filler to the desired thickness and contour. When applying to broad or deeply recessed areas, drill small holes at frequent intervals throughout the area to “anchor” the filler. Do not return leftovers from mixing filler to the filler can.

**Finishing:** Allow at least 8-10 minutes to cure before filing when temperature is 65° to 70° F.. Colder temperatures require longer. Then sand and finish for primer application of any type. Allow additional time to cure before applying Acrylics.

**Note:** DO NOT wipe over the cured filler with solvent or thinner before priming.

**Caution:** HARMFUL IF INGESTED. If ingested, consult a physician. VAPOR HARMFUL. Avoid prolonged breathing of vapor; if headache or nausea occur, remove to fresh air. SKIN AND EYE IRRITANT. Avoid prolonged or repeated contact with skin. In case of contact, flush skin and eyes with plenty of water. COMBUSTIBLE. Keep away from heat, sparks, and open flame. Keep lid closed while not in use. KEEP OUT OF REACH OF CHILDREN.

STORE IN A COOL DRY PLACE  
FORMULATED EXPRESSLY FOR THE PROFESSIONAL BODY SHOP  
MECHANIC